

11/17/2016

This exploded view diagram illustrates the assembly of a water pump system. The components are numbered as follows:

- 1:** Screws for the base plate.
- 2:** The main pump unit.
- 3, 4:** O-rings and a connector for the pump outlet.
- 5, 6:** Elbow and connector for the pump outlet.
- 7:** O-rings for the base plate ports.
- 8:** A small component, possibly a float valve or check valve.
- 9:** A small cylindrical component, possibly a filter or cap.
- 10, 11:** A vertical riser pipe and its top cap.
- 12:** A small component, possibly a float valve or check valve.
- 13:** A vertical riser pipe.
- 14, 15:** Elbow and connector for the riser pipe.
- 16, 17:** O-rings and a connector for the riser pipe.
- 18:** A small component, possibly a float valve or check valve.
- 19:** A vertical riser pipe.
- 20:** A horizontal riser pipe.
- 21:** A horizontal riser pipe.
- 22:** A small component, possibly a float valve or check valve.
- 23:** A small component, possibly a float valve or check valve.

Dometic Corporation - Sanitation Systems
13128 State Rt. 226, P.O. Box 38
Big Prairie, OH 44611-0038 USA
Telephone: 330-496-3211
Fax: 330-496-3097
Email: sealand@dometicusa.com